

HEATING


Cabin filter: Removal - Refitting

61A

AIR CONDITIONING

REMOVAL

OPERATION FOR REMOVAL OF PART CONCERNED



112763

- ☐ Unclip the passenger compartment filter (1) .

Note:

Foreign bodies (leaves, insects etc.) are likely to accumulate in the passenger compartment filter.

Remove the cabin filter with care so as to prevent foreign bodies getting into the evaporator.

- ☐ Remove the cabin filter.

REFITTING

I - REFITTING PREPARATIONS OPERATION

- ☐ Check for foreign bodies in the cabin filter housing, and clean thoroughly if necessary.

II - REFITTING OPERATION FOR PART CONCERNED

- ☐ Refit the cabin filter.
- ☐ Clip on the cabin filter.